

## P-Seal Plaster Plugs

### Description:

P-Seal Plaster Plugs are used above ground to fix any P-Seal Mesh membranes to the substrate either internally or externally.

To fix the membrane use a 8mm SDS drill bit and drill through the membrane into the substrate prior to hammering home the plaster plug. P-Seal Plaster Plugs should be fixed at maximum centres of 250mm internally or 150mm centres externally.

For above ground waterproofing use mastic to seal behind the plugs before hammering home.



### Technical Details:

**Size:** 8mm x 70mm

**Colour:** White

**Coverage:**

**Packaging:** Bag of 250

**Stud Depth:**

**Thickness:** 8mm

### Associated Products:

- P-Seal Quick Plugs - for fixing the membrane to walls
- P-Seal Brick Plugs - for fixing the membrane to walls
- P-Seal Cob Plugs - for fixing the membrane to poorer quality substrate such as cob walls
- P-Seal Rope - for sealing plugs
- P-Seal Tape - for sealing membrane joints
- P-Seal Corner Strip – for sealing wall/floor joints or protrusions through the membrane
- P-Seal Drainage Channel, Floor Drain and Aquaduct – for removal of water to evacuation points

All Permagard products are of a high quality and subject to rigid quality control. The company, however, cannot govern the conditions of usage and application of its products and any warranty, written or implied covers material only. The information contained in this leaflet is given in good faith but no liability can be assumed by the Company for any damage, loss, injury or patent infringement arising from its use. With the publication of this Technical Data Sheet all previous editions are no longer valid.

**Permagard Products Limited**

Chittingen Industrial Estate, Avonmouth, Bristol. BS11 0YB.

Tel: 0117 9381596

Web: [www.pemagard.co.uk](http://www.pemagard.co.uk)

Email: [sales@permagard.co.uk](mailto:sales@permagard.co.uk)